


GENERAL NOTES:-  
1. USE PROPER INSULATION BETWEEN ALL DISSIMILAR METALS.



### INSTALLATION PROCEDURE 1:

1. POSITION Z8E510 TO POWER PLANT FLANGE (2EA)
2. SLIP Z8E508 ELBOW OVER Z8E510, BUT DO NOT SECURE TO POWER PLANT (2EA)
3. INSTALL RIVETED NUTPLATE IN Z8E511 DUCT
4. SLIP Z8E510 COLLAR OVER Z8E511 UNTIL IT IS APPROX. EVEN WITH UPPER END OF Z8E511.
5. SLIP Z8E508 ELBOW AFT UNTIL HAND CAN GUIDE & SUPPORT Z8E510 INTO NUTPLATE. POWER PLANT ENDOUSAS MUST NOT BE DEFORMED BY ANY PRESSURES FROM THIS OPERATION.
6. SLIP Z8E508 ELBOW OVER Z8E511 & SECURE ELBOW TO POWER PLANT & Z8E511.
7. SLIP Z8E5100 INTO NUTPLATE & TIGHTEN TO NULL OPENING Z8E508B (2EA)
8. SLIP Z8E506 ONE UP AGAINST Z8E503B (2EA) & SECURE IT TO Z8E511 & Z8E505B.

## LOOKING FORWARD

NAVY NO. 2406-2855 INCL  
Contract Change "X"  
SO. 136-49

H 236

[illegible]